

## Poly-Dolly® Portable Dispensing Station #ENP5300 - 32.5" x 69" x 26.5", 1 each/package



This mobile dispensing unit is a dolly, dispensing rack and containment sump — all in one!

- Built-in 80-gallon sump
- Safe and easy way to transport and dispense from 55-gallon drums
- 100% polyethylene design with 10" wheels
- Note: This item is drop-shipped from vendor

### ENP5300 Specifications

<b>Dimensions:</b>	32.5" W x 69" L x 26.5" H
<b>Shipping Dimensions:</b>	33" W x 69" L x 27" H
<b>Sold as:</b>	1 per package
<b>Color:</b>	Yellow
<b>Composition:</b>	Polyethylene
<b>Load Capacity UDL:</b>	600 lbs. per package
<b>Sump Capacity:</b>	80 gal. per package
<b>Weight:</b>	98 lbs.
<b>Incinerable:</b>	No
<b>Ship Class:</b>	250

### Metric Equivalent Specifications

<b>Dimensions:</b>	82.6cm W x 175.3cm L x 67.3cm H
<b>Shipping Dimensions:</b>	83.8cm W x 175.3cm L x 68.6cm H
<b>Load Capacity UDL:</b>	272.2 kg per package
<b>Sump Capacity:</b>	302.8 L per package
<b>Weight:</b>	44.5 kg

## ENP5300 Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)

Chemical Compatibility (CCG)



**SpillTech**

Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)