

Containment Berm - Economy L Bracket #BERM1212E - 12' x 12' x 1', 1 each/package



Large-scale, drive-in containment helps meet regulations without breaking your budget.

- 40-mil LLDPE construction is lightweight for easy handling, storage and transportation
- Chemical-resistant berm is compatible with acids, water, oils and solvents
- Sidewalls are supported by sturdy L-shaped composite brackets
- Great for containment of drums, totes, equipment and vehicles; also ideal for decon stations or response to tank leaks

BERM1212E Specifications

| | |
|-----------------------------|-----------------------------------|
| Dimensions: | 12' W x 12' L x 1' H |
| Shipping Dimensions: | 40" W x 48" L x 14" H |
| Sold as: | 1 per package |
| Color: | Black |
| Composition: | 40 mil LLDPE / Composite Brackets |
| Sump Capacity: | 1077 gal. per package |
| Weight: | 48 lbs. |
| # per Pallet: | 8 |
| Incinerable: | No |
| Ship Class: | 175 |

Metric Equivalent Specifications

| | |
|-----------------------------|----------------------------------|
| Dimensions: | 3.7m W x 3.7m L x 30.5cm H |
| Shipping Dimensions: | 101.6cm W x 121.9cm L x 35.6cm H |
| Sump Capacity: | 4076.4 L per package |
| Weight: | 21.8 kg |

BERM1212E Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com