

6-Drum SpillPal™ Portable Containment Unit #SPAL6 - 4' x 6' x 3", 1 each/package



A SpillPal unit with flexible sidewalls provides quick, portable spill containment — a great alternative to hard poly pallets that must be moved with a forklift.

- Provides versatile, portable spill control during temporary storage of drums, machine parts, tanks and generators
- Can also be used as a washdown pad or pumping station
- Light, foam sidewalls spring back to their original shape after any pressure is applied; safe for drive-overs from handtrucks or forklifts
- Affordable, portable and easy to set up
- Reusable containment can be folded and stored to save floor space
- No ramps or other accessories are required for usage
- To help keep items out of contained liquids, optional grates can be added (grates not included, use one grate per every two drums; do not drive over SpillPal when grates are in place)
- Resists most chemicals; check your specific chemical compatibility under "Technical Resources" at spilltech.com
- Available in multiple configurations

SPAL6 Specifications

Dimensions:	6' W x 4' L x 3" H
Shipping	8" W x 51" L x 31" H
Dimensions:	
Sold as:	1 per package
Color:	Green
Composition:	20 OZ PVC fabric/foam sidewalls
Sump Capacity:	45 gal. per package
Weight:	14 lbs.
# per Pallet:	14
Incinerable:	No
Ship Class:	250

Metric Equivalent Specifications

Dimensions:	182.9cm W x 121.9cm L x 7.6cm H
Shipping	20.3cm W x 129.5cm L x 78.7cm H
Dimensions:	
Sump Capacity:	170.3 L per package
Weight:	6.4 kg

SPAL6 Technical Information

Warnings & Restrictions:

Gasoline Notice

Not for use with gasoline.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Chemical Compatibility (CCG)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com